

GUIDE

ThermaLock-1.6

MadgeTech

Distributed by AKRIBIS



HITEMP140-CF

Installation Guide

The HiTemp140-CF is designed to work with either the CF200 or the ThermaLock. Use the following instructions to install the HiTemp140-CF using either the CF200 or ThermaLock.

1

Create a 9/16" (14.3mm) hole in the empty container



2

Remove the nut from the ThermaLock, using the included wrench



3

Insert the ThermaLock into the hole with the black gasket on the outside



4

On the inside of the can, screw the nut onto the ThermaLock with the round side against the can



5

Fasten the nut with the included wrench



6

Insert the ferrule onto the HiTemp140-CF



7

Screw the HiTemp140-CF into the ThermaLock until the threads are no longer visible. This will compress the black ferrule creating a hermetic seal

